



2 ERIK CIRCLE, P.O.Box 280
Verdi, Nevada 89439
telephone (775) 689-5700
fax: (888) 492-2783
e-mail: service@wellsbloomfield.com

FAUCET CLEANING INSTRUCTIONS

Empty contents from the dispenser.

Remove faucet from dispenser:
Hold faucet firmly, then turn shank nut clockwise until the faucet is free.

Unscrew handle & plunger assembly from faucet body.

Carefully pry seat cup from handle & plunger assembly.

Wash faucet components with warm water and mild detergent.

If necessary to remove caked-on product, run a soft, round bristle brush, such as a sight glass brush, through the nozzle of the faucet body.

If necessary to remove caked-on product, brush the seat cup with a soft bristle brush.

Rinse components thoroughly with clear water.
Allow to air dry.

Reinstall seat cup on handle & plunger assembly.

Reinstall handle & plunger assembly on faucet body.

Wipe shank and shank nut with a soft cloth dampened with clean water.

Reassemble faucet to dispenser:
Line-up faucet threads with shank nut. Be sure handle of faucet is positioned straight up-and-down, then turn shank nut counter-clockwise until faucet is tightly attached.

Refill dispenser and test faucet for proper operation.



CAUTION: BURN HAZARD

Contents of server may be hot.
Use appropriate protective equipment.

